

INSTALLATION AND MAINTENANCE MANUAL

STAGEMAKER[®] SM16-20-25

English

STD-R-KHA-F-CQD-ENG



THIS PAGE INTENTIONALLY LEFT BLANK



CAUTION: Read the instructions supplied with the product before installation and commissioning.



CAUTION: Keep the instructions in a safe place for future reference.

Table of contents

| | | |
|----------|--|-----------|
| 1 | INTRODUCTION | 5 |
| 1.1 | Contact Information | 5 |
| 1.2 | Warranty | 5 |
| 1.3 | Disclaimer | 5 |
| 1.4 | Safety | 6 |
| 1.5 | Placards and Instructions | 8 |
| 2 | INSTALLATION | 9 |
| 2.1 | General | 9 |
| 2.2 | Chain Container Installation | 9 |
| 2.3 | Lubrication | 9 |
| 2.4 | Mounting | 10 |
| 2.5 | Load Hook Throat Opening | 10 |
| 2.6 | Electrical Connection | 10 |
| 2.7 | 3-Phase Power Connections | 11 |
| 3 | INITIAL START-UP | 12 |
| 3.1 | General | 12 |
| 3.2 | Correcting the Direction of Hook Travel | 12 |
| 3.3 | Operational Checks – No Load | 12 |
| 3.4 | Operational Checks – With Load | 13 |
| 4 | HOIST OPERATION | 14 |
| 5 | MAINTENANCE | 15 |
| 5.1 | Construction (Normal Position) | 15 |
| 5.2 | Hoist Motor and Brake Assembly | 16 |
| 5.2.1 | Remove Hoist Motor and Brake Assembly (see Figure 4) | 17 |
| 5.2.2 | Installing Hoist Motor and Brake Assembly (see Figure 4) | 17 |
| 5.2.3 | Hoist Motor Brake | 18 |
| 5.2.4 | Removing Hoist Motor Brake (see Figures 4 and 5) | 19 |
| 5.2.5 | Installing Hoist Motor Brake (see Figures 4 and 5) | 19 |
| 5.3 | Torque Limiter (see Figure 6) | 20 |
| 5.3.1 | Torque Limiter Adjustment (see Figure 6) | 20 |
| 5.4 | Load Chain | 21 |
| 5.5 | Maintenance Inspection | 21 |
| 5.6 | Load Chain Specifications (see Figure 7) | 23 |
| 5.7 | Removing the Load Chain | 23 |
| 5.8 | Installing the Load Chain | 24 |
| 5.9 | Fall Stop Assembly (see Figure 10) | 26 |
| 5.10 | Chain Container | 27 |
| 5.10.1 | Removing Chain Container (see Figure 11) | 27 |
| 5.10.2 | Installing Chain Container (see Figure 11) | 27 |
| 5.11 | Upper and Lower Travel Safety Limit Switch | 28 |
| 5.12 | Upper and Lower Rotary Travel Limit Switch | 29 |
| 5.13 | Hooks | 30 |
| 5.13.1 | Hook Inspection | 31 |
| 5.13.2 | Hook Dimensions | 32 |
| 5.13.3 | Body Hook | 33 |
| 5.14 | Controls | 34 |
| 5.15 | 2-Speed – 3-Phase – 208 / 230 / 460 Volt – Power Circuit | 36 |
| 5.16 | 2-Speed – 3-Phase – 208 / 230 / 460 Volt – Control Circuit | 37 |

| | | |
|----------|--|-----------|
| 5.17 | 2-Speed – 3-Phase – 208 / 230 / 460 Volt – Push Button | 38 |
| 5.18 | 2-Speed – 3-Phase – 575 Volt – Power Circuit | 39 |
| 5.19 | 2-Speed – 3-Phase – 575 Volt – Control Circuit | 40 |
| 5.20 | 2-Speed – 3-Phase – 575 Volt – Push Button | 41 |
| 6 | PREVENTATIVE MAINTENANCE | 42 |
| 6.1 | Maintenance and Inspection Table..... | 42 |
| 6.2 | Lubrication | 43 |
| 6.3 | Recommended Technical Support for Various Spare Parts | 44 |
| 6.4 | Screw Tightening Torque (lb-ft) Specification | 44 |
| 6.5 | Troubleshooting | 45 |
| 7 | PARTS ILLUSTRATIONS..... | 46 |
| 7.1 | Basic Hoist Assembly | 46 |
| 7.2 | Hoist Gearbox Components | 48 |
| 7.3 | SM16 / SM20 / SM25 Hoist Motor and Brake Assembly..... | 50 |
| 7.4 | Lifting Assembly – SM16 Only..... | 52 |
| 7.5 | Lifting Assembly – SM20/25 Only..... | 54 |
| 7.6 | SM16 / SM20 / SM25 Electrical Control Assembly | 56 |
| 7.7 | Push Button Assembly –Vertical Pairs of Buttons | 58 |

1 INTRODUCTION

1.1 Contact Information

Please do not hesitate to use the following contact information in the event that you may need assistance:

R&M MATERIALS HANDLING, INC.

4501 Gateway Boulevard

Springfield, OH 45502

General Telephone: 937 - 328-5100

Toll Free Telephone (US): 800 - 955-9967

General Fax: 937 - 325-5319

Parts Department Fax (US): 800 - 955-5162

Parts Dept. Fax (other): 937 - 328-5162

Website: www.rmhoist.com

1.2 Warranty

All sales are subject to the R&M Materials Handling, Inc. Standard Terms and Conditions of Sale (Revision 101707), a copy of which is available at www.rmhoist.com or upon request from R&M Materials Handling, Inc. customer service/sales representatives and the terms of which are incorporated as if fully rewritten herein.

1.3 Disclaimer

This manual has been prepared by R&M MATERIALS HANDLING, INC. to provide information and suggestions for hoist installation, maintenance, and inspection personnel. This manual should be used in conjunction with the **STAGEMAKER**[®] COMPACT Concert Hoist Operator's Manual to teach safe operating practices to all personnel associated with hoist operations and maintenance.

It is NOT intended that the recommendations in this manual take precedence over existing plant / site safety rules and regulations or OSHA regulations. However, a thorough study of the following information should provide a better understanding of proper installation, maintenance, and inspection procedures that are to be followed in order to afford a greater margin of safety for people and machinery in the area of hoist operations.

It must be recognized that this is a manual of recommendations for the Hoist Installation, Maintenance, and Inspection personnel and its use is permissive, not mandatory. It is the responsibility of the hoist owner to make personnel aware of all federal, state, and local codes and regulations. The owner is responsible for providing instruction and ensuring that certain installation, maintenance, and inspection personnel are properly trained.

1.4 Safety

Read and understand this manual before using the hoist.

Important issues to remember during installation, operation, maintenance, and inspection are provided at the hoist control stations, at various locations on the hoist, in this manual, and in the **STAGEMAKER® COMPACT Concert Hoist Operator's Manual**. These issues are indicated by **DANGER**, **WARNING**, or **CAUTION** instructions or placards that alert personnel to potential hazards, proper operation, load limitations, and more.



DANGER: Indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.



WARNING: Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.



CAUTION: Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Taking precedence over any specific rule, however, is the most important rule of all:

“USE COMMON SENSE”

It is a responsibility of the hoist owner / user to establish programs to:

1. Train and designate hoist operators, and
2. Train and designate hoist inspectors / maintenance personnel.

The words SHALL and SHOULD are used throughout this manual in accordance with definitions in the ASME B30 standards as follows:

SHALL indicates a rule is mandatory and must be followed.

SHOULD indicates a rule is a recommendation, the advisability of which depends on the facts in each situation.

Hoist operation, hoist inspection, and hoist maintenance personnel training programs should be based on requirements in accordance with the latest edition of:

- **ASME B30.16 Safety Standard for Overhead Hoists (Underhung)**

Such training should also provide information for compliance with any Federal, State, or Local Code requirements, and existing plant safety rules and regulations.

If an overhead hoist is installed as part of an overhead crane or monorail system, training programs should also include requirements in accordance with the latest editions, as applicable, of:

- **ASME B30.11 Safety Standard for Monorails and Underhung Cranes**
- **ASME B30.17 Safety Standard for Overhead and Gantry Cranes, Top Running Bridge, Single Girder, Underhung Hoist.**



NOTE: It is a responsibility of the owner / user to install, inspect, test, maintain, and operate a hoist in accordance with the ASME B30.16 Safety Standard, OHSA Regulations, and ANSI / NFPA 70, National Electric Code. If the hoist is installed as part of a total lifting system, it is also the responsibility of the owner / user to comply with the applicable ASME B30 volume that addresses other types of equipment used in the system.



NOTE: Further, it is the responsibility of the owner / user to require that all personnel who will install, inspect, test, maintain, and operate a hoist read the contents of this manual, **STAGEMAKER®** Concert Electric Chain Hoist Operator's Manual, ASME B30.16 Safety Standards for Overhead Hoists (Underhung), OHSA Regulations, and ANSI / NFPA 70, National Electric Code. If the hoist is installed as part of a total lifting system, all personnel must also read the applicable ASME B30 volume that addresses other types of equipment used in the system.



DANGER: Failure to read and comply with any one of the limitations noted in this manual can result in product failure, serious bodily injury or death, and / or property damage.

R&M MATERIALS HANDLING, INC. has no direct involvement or control over the hoist's operation and application. Conforming to good safety practices is the responsibility of the owner, user, and operating personnel.

Only those Authorized and Qualified Personnel who have shown that they have read and have understood this manual and the **STAGEMAKER®** Concert Electric Chain Hoist Operator's Manual should be permitted to operate the hoist.

The owner / user **SHALL** ensure that all operators read and understand the **STAGEMAKER®** Concert Electric Chain Hoist Operator's Manual prior to operating the hoist.

1.5 Placards and Instructions

READ and OBEY all Danger, Warning, Caution, and Operating Instructions on the hoist and in this manual and **STAGEMAKER[®] Concert Electric Chain Hoist Operator's Manual**. Make sure that all placards are in place and legible.

Failure to comply with safety precautions in this manual and on the hoist is a safety violation that may result in serious injury, death, or property damage.

2 INSTALLATION



DANGER: Before installing, removing, inspection, or performing any maintenance on a hoist, the main switch shall be de-energized. Lock and tag the main switch in the de-energized position in accordance with ANSI Z244.1. Follow other maintenance procedures outlined in this manual and ASME B30.16.

2.1 General

Prior to installation, the unit shall be checked thoroughly for damage during shipment or handling at the job site.

Each complete electric chain hoist is load tested at 125% of the nameplate-rated capacity.

All hoists are designed for the type of mounting specified by the purchaser. The adequacy of the supporting members (monorail beams, cranes, hangers, supports, framing, etc.) is the responsibility of user / owner and shall be determined or verified by qualified personnel.

Read the instructions contained in this manual and the **STAGEMAKER®** Concert Electric Chain Hoist Operator's Manual as well as any other related manuals. Observe the warning tags attached to the unit before the installation is started.

2.2 Chain Container Installation



CAUTION: Remove small chain connecting chain container to hoist body. This chain is to be used only during installation and must then be removed.

Due to the weight of the chain and chain container on all models **SM16 / 20 / 25**, the chain container is attached to the hoist body with a LIGHT DUTY chain to facilitate removing hoist and chain container from packing container for assembly of chain container to hoist body.

2.3 Lubrication

The hoist gear case comes completely pre-lubricated with oil.



NOTE: Open trolley wheel gearing has not been greased at the factory. See the trolley manual for proper gear lubricant to use before installing hoist.


The load chain requires lubrication prior to first use. Chain lubricant is included with shipment of each new chain hoist.

2.4 Mounting

Below are three types of mounting:

- 1) Hook Mounted
- 2) Base Mounted
- 3) Coupling Mounted
- 4) Trolley Mounted (NOT SHOWN)

Figure 1. Mounting Types



For all trolley-mounted hoists, refer to appropriate trolley manual for trolley installation instructions.

After a trolley-mounted hoist has been assembled to a beam, check for balance. Each trolley-mounted hoist is balanced at the factory for “as shipped” condition. Any auxiliary devices (radio control, lights, hose reels, etc.) furnished and mounted by “others” may require additional counterweight. Hoists must hang straight without a load or there will be a noticeable “kick” when a load is applied to the hook. An unbalanced hoist / trolley may result in damage to equipment.

2.5 Load Hook Throat Opening



CAUTION: ANSI B30.16-1998 recommends that the throat opening of a load hook be measured and recorded prior to putting a hoist into service and that a gauge be made to provide a quick visual inspection for a bent hook as required during routine inspections. Record this information before initial start-up. See section 5.13 for more detailed hook information.

2.6 Electrical Connection


The user / owner must provide the main power supply hardware (cable, conductor bar, fuses, disconnect switch, etc.).



CAUTION: Make sure that the power supply voltage is the same as that shown on hoist serial plate / nameplate. Make sure that fuses and other current overload devices are in place to protect the power supply. Make sure that power cable or conductors have sufficient capacity to maintain the hoist supply voltage by ± 5 percent of nominal voltage under all operating conditions. Poor voltage regulation may cause motor overheating or sluggishness, and chattering / inoperative motor brake(s) and controls. Do not use power supply cables with solid conductors.

2.7 3-Phase Power Connections

Figure 2. 3-Phase Power Connections



PS – Power supply

TR – Trolley connection

PB – Pushbutton connection

1. Remove the control enclosure cover.
2. Insert the power supply cable through the cable gland or connector (PS).
3. Connect phases L1, L2, L3, and ground (PE) to terminal strip. Refer to the wiring diagram.
4. Tighten the terminal screws
5. Tighten the cable gland or connector to secure the cable.
6. Connect the pushbutton assembly to plug connector X23 (PB).
7. Connect the motorized trolley plug connector X24 (TR) (optional).
8. Close the control enclosure cover.

3 INITIAL START-UP



WARNING: Before connecting power to hoist, check all “motion” buttons on the control assembly to make sure that they operate freely without binding or sticking. Check pendant cable and strain relief connection, if applicable, to ensure that they are not damaged.

3.1 General

Initial start-up procedures are as follows:

- Read all attached **WARNING** tags and placards affixed to hoist.
- Oil load chain generously over entire length of chain.
- Make sure that load chain is not twisted. If it is, untwist load chain before using.
- Make sure fall stop is placed at least 6” [150 mm] from last chain link on free end.
- Install chain container.
- If furnished, make sure that trolley wheels have proper spacing in relation to beam flange. See appropriate trolley manual for details.
- Check direction of hook travel to make certain that it corresponds to respective control button that is depressed. That is, does the load hook (normal position) or hoist body (inverted position) travel “UP” when **UP BUTTON** is depressed? If OK, go to section 3.3. If not, proceed to section 3.2 for correcting direction of travel.

3.2 Correcting the Direction of Hook Travel



WARNING: DO NOT change control leads in control enclosure or at motor relays. DO NOT change nameplates on controller. The upper/lower safety limit switch is wired in series with “UP” control circuit as furnished from factory. Changing controller leads or nameplates will prevent the upper safety travel limit switch from functioning properly.

Reversing any two power leads of a three-phase AC motor will reverse the direction of rotation.

- Reverse any two leads of a three-phase power motor at the main power source or at motor connections.
- **Do not change internal wiring of hoist.**
- After changing two leads of the main power, recheck direction of rotation. Press “UP” button only. If hook travel goes in “UP” direction, proceed to section 3.3. If not, redo section 3.2.

3.3 Operational Checks – No Load

- Check hoist motor brake function. Run empty load hook up or down to check that load hook does not drift more than 1.0 inch [25mm]. If so, adjust brake as described in Section 5.2 of this manual.
- Run empty load hook down to check that fall stop (located on free end of load chain) makes proper contact with upper / lower travel safety limit switch and that limit switch functions properly.
- Run empty load hook up to check that load hook makes proper contact with upper / lower travel safety limit switch and that limit switch functions properly.
- Run empty load hook up and down several times while checking for proper tracking of load chain.

3.4 Operational Checks – With Load

- After completion of no-load operational tests, the user/owner should perform a full load test even though each complete hoist is load tested at factory.
- Lift a near capacity load about one (1) foot [30cm] above floor level. Check that the brake holds load. Also, check stopping capability of brake when lifting to a stop and lowering to a stop.
- Move trolley the full length of monorail or crane beam. Check for any binding of trolley wheels on flange and/or interference at splice joints, hanger connections / bolts, etc.
- Check contact with stops. Contact with stops SHALL only be made with trolley bumpers. Stops that are designed to make contact with wheels SHALL NOT be used.

4 HOIST OPERATION



WARNING: Before proceeding with the normal operation of this hoist, the operator(s) shall be trained in accordance with the STAGEMAKER[®] Concert Electric Chain Hoist Operator's Manual as supplied with this hoist.




WARNING: failure to read and comply with any one of the limitations noted in this manual and the STAGEMAKER[®] Concert Electric Chain Hoist Operator's Manual furnished with this hoist can result in product failure, serious bodily injury or death, and / or property damage. Refer to section 1.0 of this manual for contact information if you need any additional assistance.

5 MAINTENANCE

5.1 Construction (Normal Position)

Figure 3. Construction (Normal Position)



1. BODY HOOK
2. HOIST MOTOR
3. GEAR CASE & GEARING
4. LOAD HOOK ASSEMBLY
5. CHAIN CONTAINER
6. CHAIN SPROCKET
7. CONTROLS & ENCLOSURE


5.2 Hoist Motor and Brake Assembly

The hoist motors are designed to provide dependable hoisting service. The standard motors are enclosed for IP55 protection against normal hazards of dust and moisture. The motor bearings are sealed and do not require further greasing.



DANGER: Before installing, removing, inspection, or performing any maintenance on a hoist, the main switch shall be de-energized. Lock and tag the main switch in the de-energized position in accordance with ANSI Z244.1. Follow other maintenance procedures outlined in this manual and ASME B30.16.

Figure 4. Hoist Motor and Brake Assembly



1. Hex head cap screw – three (3)
2. Brake and fan cover
3. Fan lock collar
4. Fan
5. Motor mounting bolt / threaded rod – three (3)
6. Hoist motor
7. Hex head cap screw – three (3)
8. Motor brake assembly
9. Friction rotor
10. Snap ring
11. Brake hub

5.2.1 Remove Hoist Motor and Brake Assembly (see Figure 4)

1. Remove load from load hook assembly.
2. Raise load hook assembly to hoist body. Allow slack in chain to permit tying up load hook assembly to remove weight from load chain.
3. Remove and lockout power to the hoist.
4. Remove three-sided branding cover.
5. Remove three (3) screws (item 1) and take off Brake and Fan Cover (item 2).
6. Remove brake coil leads from terminals inside hoist electrical control enclosure.
7. Loosen brake cable gland on electrical control enclosure and pull out brake cable.
8. Remove hoist motor leads from K25 and K10 contactors located in hoist electrical control enclosure.
9. Loosen motor cable gland on electrical control enclosure and pull out motor leads.
10. Remove screws and remove electrical control enclosure from hoist motor.
11. Remove screw and remove mounting bracket from hoist motor.
12. Remove three lock nuts from threaded rods (item 5) and pull hoist motor and brake assembly out away from gearbox.


5.2.2 Installing Hoist Motor and Brake Assembly (see Figure 4)

1. Mount hoist motor to gearbox making sure hoist motor is positioned properly. Push hoist motor into gearbox until tight and threaded rods (item 5) are through end flange of hoist motor.
2. Use lock nuts to draw hoist motor in place against the gearbox. Tighten lock nuts evenly as the hoist motor moves into place.
3. Mount brackets to hoist motor and tighten socket head cap screw.
4. Mount electrical control enclosure to hoist motor and tighten four (4) screws.
5. Insert hoist motor cable through motor cable gland on electrical control enclosure and reconnect motor leads to K25 and K10 contactors. Tighten hoist motor cable gland.
6. Insert hoist motor brake leads through brake cable gland on electrical control enclosure and reconnect hoist motor brake leads. Tighten hoist motor brake cable gland.
7. Recheck tightness of lock nuts holding hoist motor.
8. Mount end cap and tighten socket head cap screws. (Do not over-tighten).
9. Replace three-sided branding panel.
10. Untie the load hook assembly.
11. Unlock power and turn on.
12. Press "UP" button and check for proper phase rotation. If not correct, turn off power and change the position of two of the three power leads that were just reconnected.
13. If direction is correct, perform a no-load check and then a full load check per section 3.3 and 3.4 respectively.

5.2.3 Hoist Motor Brake

The hoist motor brake is a D.C. electromagnetic disc brake and does not require adjustment. The brake brings the load to a smooth and quick stop and holds the load when the hoist motor is not energized. An energized coil releases the hoist motor brake and permits the raising and lowering of the load.

Figure 5. Hoist Motor Brake



1. Brake Spring
2. Brake Armature Plate
3. Friction Rotor
4. Brake Hub
5. Brake Adjusting Rod
6. Brake Mounting Screw
7. Screw
8. Wear Plate



NOTE: MAXIMUM ALLOWABLE GAP IS 0.5mm or 0.020 inches. Remove round plastic dust cap on the side of the brake assembly. Turn off power to hoist, insert gauge pin of proper diameter to check motor brake gap. Recommend that a gauge pin set be available with increments of 0.001" ranging from 0.015" to 0.020".

Gap may be measured periodically to predict replacement based upon frequency of use. Replace the friction rotor when the gap reaches the maximum allowable dimension.

5.2.4 Removing Hoist Motor Brake (see Figures 4 and 5)

1. Remove load from load hook assembly.
2. Raise load hook assembly to hoist body. Allow slack in chain to permit tying up load hook assembly to remove weight from load chain.
3. Remove and lockout power to the hoist.
4. Remove three-sided branding cover.
5. Remove three (3) screws (item 1 - Figure 4) and take off Brake and Fan Cover (item 2 - Figure 4).
6. Remove lock collar (see Figure 5) and remove fan. If needed, use two screwdrivers under hub to pry fan loose.
7. Remove second retaining ring and pull out spacer.
8. Remove brake coil leads from terminals inside hoist electrical control enclosure.
9. Loosen brake cable gland and pull out brake cable as necessary.
10. Remove three (3) screws (see Figure 5) from brake magnetic assembly. Remove brake magnetic assembly.
11. Remove motor brake friction rotor (item 3 - Figure 5).
12. Remove three (3) screws (item 7 - Figure 5) and remove wear plate (item 8 - Figure 5).

5.2.5 Installing Hoist Motor Brake (see Figures 4 and 5)

1. Check the voltage of the motor brake assembly. It must match the voltage of the motor.
2. Attach wear plate (item 8 - Figure 5) to hoist motor end flange and tighten three (3) screws (item 7 - Figure 5) to recommended tightening torque – 6.6 lb-ft [9Nm].
3. Slide friction rotor (item 3 - Figure 5) onto brake hub (item 4 - Figure 5).
4. Mount magnetic brake assembly (item 1 - Figure 5) and tighten three (3) screws (item 6 - Figure 5) to recommended tightening torque – 6.6 lb-ft [9 Nm].
5. Insert spacer and install snap ring into groove just above spacer.
6. Mount fan (item 4 - Figure 4) and install lock collar just above fan hub.
7. Insert motor brake leads through brake cable gland on electrical control enclosure and reconnect motor brake leads. Tighten motor cable gland.
8. Mount end cap and tighten three screws. (Do not over-tighten).
9. Replace branding cover.
10. Turn on power.
11. Free the bottom block and make certain load chain is not twisted.
12. Perform no-load test and load test per sections 3.3 and 3.4 respectively.


5.3 Torque Limiter (see Figure 6)

The hoist is equipped with a torque limiter that is located in the gearbox assembly. The torque limiter is a safety device that prevents lifting excessive loads that may damage the hoist. The torque limiter is a friction type slip clutch that couples the motor to the gear train.

5.3.1 Torque Limiter Adjustment (see Figure 6)

1. Remove three-sided branding panel.
2. Use two small straight-slot screwdrivers and remove plastic cap from center of gearbox cover.
3. Loosen locking screw (item 16).
4. Use a 46mm socket to turn the adjusting nut (item 15).
5. Turn nut in required direction:
 - INCREASE CAPACITY – Turn nut clockwise to increase torque.
 - DECREASE CAPACITY – Turn nut counterclockwise to decrease the torque AND then clockwise $\frac{1}{4}$ turn.
6. Set limiter equal to or 5 percent less than 125 percent of nameplate capacity.
7. Tighten locking screw (item 16).
8. Replace plastic cap.
9. Replace three-sided branding panel.

Figure 6. Torque Limiter Adjustment



5.4 Load Chain




CAUTION: A hoist **SHALL NEVER** be used if the load chain shows any evidence of mechanical damage or excessive wear. Never use the load chain as a sling. Use only original equipment chain as supplied by a factory authorized source. Improper load chain storage or installation can render the load chain unusable prior to the first lift.

5.5 Maintenance Inspection

A qualified person **SHALL** be designated to routinely conduct an in-depth inspection of the load chain (See Section 6 – Preventative Maintenance for schedule recommendations). This designated person **SHALL** inspect load chain using good judgment in evaluating the remaining service life. Any deterioration of load chain resulting in appreciable loss of original strength **SHALL** be noted and evaluated.

An in-depth inspection **SHALL** include a written record that is dated and signed by the inspector.

Figure 7. Chain Dimensions



Measure the following chain dimensions at several points on chain: (see Figure 7)

- Dimensions of one link ($d \times t$) where, d = diameter and t = pitch
- Length over 11 links ($11t$)

Replace load chain if any one of these dimensions exceed maximum allowed wear.

| | | SM16 | SM20 / 25 |
|-------------------------------|--------|-------------------------|--------------------|
| Maximum allowed wear: | | 9.0 x 27.0 chain | 11.3 x 31.0 |
| Minimum link diameter allowed | (d): | 0.319" [8.1 mm] | 0.398" [10.1 mm] |
| Maximum pitch allowed | (t): | 1.114" [28.3 mm] | 1.280" [32.5mm] |
| Maximum length allowed | (11t): | 11.929" [300 mm] | 13.681" [347.5 mm] |



NOTE: If load chain needs replaced, then inspect chain guide and chain (load) wheel on hoist and idler sprocket in 2-fall load hook assembly for excessive wear. A chain sprocket showing evidence of scored pockets or sharp edges generated from wear SHALL be replaced. A worn chain sprocket or idler sprocket can greatly reduce the life of load chain.

5.6 Load Chain Specifications (see Figure 7)

Table 1. Load Chain Specifications

| Hoist Type: | SM16 | SM20 / SM25 |
|-------------------------------|--|--|
| Chain Specification: | Load chain - 9.0 x 27.0 | Load chain - 11.3 x 31.0 |
| Chain type: | Standard | Standard |
| Diameter (ød) x pitch (t): | 0.3543 x 1.0629 in [9.0 x 27.0 mm] | 0.4449 x 1.2205 in [11.3 x 31.0 mm] |
| Length over 11 links (11t): | 11.6929" [297 mm] | 13.4251" [341 mm] |
| Class: | DAT | DAT |
| Grade: | H8S or HE G80 RAS | H8S or HE G80 RAS |
| Maximum working stress: | 123.4 N/mm ² | 122.3 N/mm ² |
| Hardened surface: | 580 or 700 HV | 580 or 700 HV |
| Thickness: | 0.18 to 0.45 mm | 0.21 to 0.52 mm |
| Standard: | DIN 5684 – 8 | DIN 5684 - 8 |
| Marking (10 x t): | 1 or 16 H8S or A8 | 1 or 16 H8S or A8 |
| Maximum working load, 1 fall: | 3527 lbs. [1600 kg] | 3 STONS (3000 lbs.) [2722 kg] |
| Breaking load: | 93 kN | 160 kN |
| Maximum breaking stress: | 116,030 lbs/in ² (800 N/mm ²) | 116,030 lbs/in ² (800 N/mm ²) |
| Total breaking elongation: | >10% min. | >10% min. |
| Weight for 100 links: | 1.8 kg | 2.85 kg |

5.7 Removing the Load Chain

1-FALL CHAIN

1. Remove load from load hook assembly or hoist body hook if inverted.
2. Remove load hook assembly from load chain. Some disassembly of 1-fall load hook assembly is required.
3. Attach a 12" [300 mm] or longer zip tie to the end of the load hook assembly end of the chain.
4. Run hoist in "UP" direction until all of chain is in container.
5. Remove chain container with all of old chain in chain container.
6. Remove fall stop from old chain and save for use with new chain.

2-FALL CHAIN

1. Remove load from hook block assembly.
2. Run hoist in "UP" direction until hook block assembly is about 1.0 foot [30cm] from hoist body.
3. Unfasten load chain from chain anchor mounted on hoist body.
4. Remove load hook assembly from load chain by allowing chain to run through it.
5. Run hoist in "UP" direction until all of the chain is in the container.
6. Remove chain container with old chain.
7. Remove fall stop from old chain save for use with new chain.

5.8 Installing the Load Chain

Figure 8. Installing the Load Chain





Figure 9. Load Chain Insertion



1-FALL CHAIN INSTALLATION

1. Attach a 12" [300 mm] or longer zip tie to the last link of the chain (item 1 - Figure 8).
2. Insert the zip tie into chain opening closest to the center of the hoist ("UP" direction) by slowly feeding it through the chain sprocket.
3. Ensure that the chain is laying correctly on the sprocket and chain guides, then, while holding the zip tie taut, continue to feed the chain through the sprocket until it emerges out the other side.



CAUTION: Make sure the chain weld on chain link faces inward toward chain wheel pocket on hoist load sprocket.

4. Run hoist "UP" to feed the rest of the chain through the sprocket and out other side.
5. Attach fall stop at least 6 inches [150mm] from end of chain closest to the center of the hoist. Attach load block assembly on other end of load chain. Refer to Figure 10 for details.
6. Make sure that load chain is not twisted or deformed.
7. Attach chain container. Lubricate chain.

2-FALL CHAIN INSTALLATION

1. Attach a 12" [300 mm] or longer zip tie to the last link of the chain (item 1 - Figure 8).
2. Insert the zip tie into chain opening closest to the center of the hoist ("UP" direction) by slowly feeding it through the chain opening closest to the center of the hoist.
3. Ensure that the chain is laying correctly on the sprocket and chain guides, then, while holding the zip tie taut, continue to feed the chain through the sprocket until it emerges out the other side.



CAUTION: For a 2-fall load hook assembly, make sure the chain weld on chain link faces inward toward chain wheel pocket on hoist and away from idler sprocket of load hook assembly. Follow steps outlined below:

4. Run hoist in slow speed to feed chain through chain sprocket. Continue running until about 2.0 feet [60 cm] of chain is available out the other side.
5. Slide chain onto idler sprocket of load hook assembly making sure not to twist chain while inserting it. Link weld must face away from idler sprocket on load block assembly.
6. Attach chain anchor and chain to hoist body. Tighten chain anchor bolts per recommended torque settings in Section 6.4.
7. Attach fall stop 6.0 inches [150 mm] from end of chain closest to the center of the hoist. See Figure 10 for details.
8. Make sure that chain is not twisted or kinked.
9. Attach chain container.


After chain installation:

1. Without a load, run chain up and down a few times to make sure load chain is not twisted. If it is, remove chain twist.
2. Lubricate load chain.

5.9 Fall Stop Assembly (see Figure 10)

The slack fall stop is a safety not a functional stop. The fall stop must be located at least (6.0) inches [150mm] from end of load chain.

Figure 10. Fall Stop Assembly



Removing Fall Stop Assembly


1. Loosen and remove one nut for SM16 (two for SM20/25)
2. Remove bolts.
3. Remove two halves of Fall Stop.
4. Remove limit switch washer plate and spring.

Installing Fall Stop Assembly

1. Install limit switch washer plate and spring onto chain. Make certain washer is in proper position to contact limit switch.
2. Place two halves of Fall Stop at least six (6) inches [150mm] from end of chain.
3. Insert bolt and tighten one nut for SM16 (two for SM20/25)

5.10 Chain Container

Figure 11. Chain Container



CAUTION: Chain container must be installed for effective operation of hoisting limit switch.

5.10.1 Removing Chain Container (see Figure 11)

1. Remove load from load hook assembly.
2. Lower load hook assembly to its lowest point. This will remove weight of chain from chain container.
3. Support chain container before removing chain.
4. Remove snap ring (item 3) from end of pin (item 1). There is a snap ring on each end of pin.
5. Pull pin (item 1) out while supporting chain container (item 4).
6. Remove chain container (item 4).

5.10.2 Installing Chain Container (see Figure 11)

1. Place end of load chain into chain container (item 4). Position chain container (item 4) onto hoist mounting bracket (item 2).
2. Align holes and insert pin (item 1) through container (item 4) and hoist mounting bracket (item 2).
3. Install snap ring (item 3) on end of pin (item 1). Verify that snap ring is properly seated in groove on pin.
4. Raise load hook and verify that chain is going into chain container without problems.

5.11 Upper and Lower Travel Safety Limit Switch

The Upper and Lower Travel Limit Switch is an automatic reset type switch and connected to the control circuit. The switch housing is recessed into the underside of hoist body.



CAUTION: The primary limit device that controls the upper limit of travel is an emergency device only. It shall not be used as an operational means to stop travel during normal operations. Do not permit continuous contact between the hoist body and the load block / fall stop assembly.

When mounted in the NORMAL position, the load hook assembly activates the upper limit switch as it contacts the limit switch that is located on bottom side of hoist body. Once switch is activated, the "UP" circuit is opened. The fall stop activates the lower limit switch when load hook assembly is lowered to its lowest travel position. The limit switch is activated and opens the "DOWN" circuit.

The lower limit position is adjustable between the lowest travel and maximum lift. A fall stop SHALL always be located at least 3 feet [91.4 cm] from end of last chain link. The upper limit position is adjustable only when an additional fall stop assembly is added (1-fall units only) between the load hook assembly and the hoist body.

5.12 Upper and Lower Rotary Travel Limit Switch

The rotary limit switch is adjustable and provides over-travel protection for the upper and lower limits of hoist travel. The limit switch is connected to the control circuit.




NOTE: Rotary limit switch assembly cannot be added to a hoist. The hoist must have the rotary limit switch assembly provided at time of initial production.

Adjustment

The position of the air-gap between the two discs (red – gray) determines the stopping place. This position can be found by gently turning the two discs. The length of air gap determines length of reset play in opposite direction.

Figure 12. Air-gap Adjustment



To reset the rotary limit once it has tripped, the load block assembly must travel approximately 11" [27cm] in opposite direction.




NOTE: The geared limit switch is not designed as a precision limit switch and should be used as a safety stop only. The geared limit switch accuracy is dependent on the height of the fall (accurate to within +/- 15").

5.13 Hooks

Check hooks for deformation or cracks. Hooks must be replaced if throat opening has increased by more than 15%, or if throat opening has more than 10-degree twist from plane of straight hook.

Figure 13. Hooks



Due to many types and sizes of hooks that can be furnished and/or specified by the user / owner, it is recommended that user / owner measure the actual throat opening of hook as originally furnished (see Figure 12). Record the throat dimension on above sketch. Retain as a permanent record. This record can then be used for determining when hook must be replaced due to deformation or excessive throat opening.



CAUTION: Abuse or overloading of hoist is indicated when any hook is twisted or has a throat opening in excess of normal. Other load bearing components **SHALL** be checked for damage.



CAUTION: Safety latches **SHALL** be replaced if missing, bent, or broken.



CAUTION: A safety latch **SHALL** function properly at all times.



CAUTION: Repairing hooks by welding or reshaping is strictly forbidden.

5.13.1 Hook Inspection


The wear on the body hook and the load hook shall be checked routinely. Measure the throat opening (dimension a_2 – Figure 14). If the throat opening exceeds the maximum opening allowed ($1.15 \times a_2$), replace the hook. Damaged safety latches shall be replaced immediately.

Table 2. Maximum throat opening allowed

| Hook class: | 05T | 08T | 1T | 16T | Body Hook |
|--------------------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Maximum allowed opening: | 1.54" [39mm] | 1.69" [43mm] | 1.81" [46mm] | 2.01" [51mm] | 2.13" [54mm] |

5.13.2 Hook Dimensions

Figure 14. Hook Dimensions



BODY HOOK

LOAD HOOK

Table 3. Hook Dimensions

| Hook Data | | | | | Dimensions inch / [mm] | | | | | | | | | | | |
|------------|-----------|-------------|---------------|---------------|------------------------|---------------|---------------|---------------|---------------|---------------|----------------|---------------|---------------|---------------|---------------|---------------|
| Cap Ton | Cap kg | Test lbs | Hoist Fall | Hook Class | øM | ø a1 | øa2 | a3 | b1 | b2 | e1 | h1 | h2 | t1 | t2 | øa2 max |
| 1 1/2 | 1600 | 7055 | SM16 1 | 05 T | 0.787 [20] | 1.693 [43] | 1.339 [34] | 1.929 [49] | 1.412 [29] | 0.945 [24] | 4.134 [105] | 1.457 [37] | 1.220 [31] | 1.693 [43] | 0.551 [14] | 1.535 [39] |
| 2 | 2000 | 8818 | SM20 1 | 08 T | 0.945 [24] | 1.890 [48] | 1.496 [38] | 2.125 [54] | 1.378 [35] | 1.142 [29] | 4.528 [115] | 1.732 [44] | 1.457 [37] | 2.087 [53] | 0.709 [18] | 1.693 [43] |
| 2 1/2 | 2500 | 11023 | SM25 1 | 08 T | 0.945 [24] | 1.890 [48] | 1.496 [38] | 2.125 [54] | 1.378 [35] | 1.142 [29] | 4.528 [115] | 1.732 [44] | 1.457 [37] | 2.087 [53] | 0.709 [18] | 1.693 [43] |
| 3 | 3200 | 14110 | SM25 1 | 08 T | 0.945 [24] | 1.890 [48] | 1.496 [38] | 2.125 [54] | 1.378 [35] | 1.142 [29] | 4.528 [115] | 1.732 [44] | 1.457 [37] | 2.087 [53] | 0.709 [18] | 1.693 [43] |
| | | | SM16 2 | 1 T | 0.945 [24] | 1.969 [50] | 1.575 [40] | 2.244 [57] | 1.496 [38] | 1.26 [32] | 4.724 [120] | 1.89 [48] | 1.575 [40] | 2.323 [59] | 0.945 [24] | 1.811 [46] |
| 4 | 4000 | 17637 | SM20 2 | 16 T | 1.181 [30] | 2.205 [56] | 1.772 [45] | 2.520 [64] | 1.772 [45] | 1.496 [38] | 5.315 [135] | 2.205 [56] | 1.890 [48] | 2.638 [67] | 0.945 [24] | 2.008 [51] |
| 5 | 5000 | 22046 | SM25 2 | 16 T | 1.181 [30] | 2.205 [56] | 1.772 [45] | 2.520 [64] | 1.772 [45] | 1.496 [38] | 5.315 [135] | 2.205 [56] | 1.890 [48] | 2.638 [67] | 0.945 [24] | 2.008 [51] |

Mark: ISO 2766


DIN model number: 15401

DIN 15400 class: T

DIN 15401 material: 35 CD 4

5.13.3 Body Hook

Figure 15. Body Hook



Removing Body Hook

1. Place hoist on workbench. Protect limit switches on bottom of hoist.
2. There are two pins holding body hook in place. Remove retaining ring and washer on one end of each pin.
3. Pull pins out and remove hook. Keep washers and snap rings.



CAUTION: Proper installation of the body hook is critical for proper hoist balance.

Installing Body Hook

1. Place hoist on workbench. Protect limit switches on bottom of hoist.
2. Verify if hoist is 1-fall or 2-fall configuration. The hook is symmetrical and can be positioned two different directions. It is important to place body hook in correct position. Verify position of body hook with the above drawing.
3. Place body hook in location. Install pins and retaining hardware. Verify that snap ring and washer are securely in place on each end.

5.14 Controls

The two-speed hoists are available for 208, 230, 460, 575 VOLT – 3 phase – 60 hertz power supplies. The controls of the two-speed hoists are **NOT** re-connectable because the hoist motors are voltage specific.



NOTE: The controls of the motorized trolley drive are not voltage re-connectable. Consult the motorized trolley manual if a voltage changeover is required.

The control panel on the hoist includes a fuse (F100) for control circuit protection.

Table 4. Control Circuit Fuses


| Control Voltage | Size |
|-----------------|--------|
| 115 VAC | 1.25 A |
| 48 VAC | 1.25 A |

Table 5. Control Circuit Components, Terminals, and Connections.

| Power & Motor Supply | | | Pushbutton | X23 Plug Pin No: | Function | |
|----------------------|--------------------|----------|-----------------|---------------------|----------|----------------------|
| L1 | Hoist Supply | | | | Terminal | |
| L2 | Hoist Supply | | Common | X23: 1 | 1-2 | Thermal protection |
| L3 | Hoist Supply | | Up | X23: 2 | 2-3 | Upper limit switch |
| K21-2 | (-) Brake | | Down | X23: 3 | 4-5 | Lower limit switch |
| K21-4 | (+) Brake | | Hoist Fast | X23: 4 | ID | Description |
| K10-1 | U1-U2 Motor Supply | | E-Stop | X23: 5 | K10 | E-stop contactor |
| K25-R3 | 1V Motor Supply | | Trolley Right | X23: 6 | K21 | Up contactor |
| K25-3 | 2V Motor Supply | | Trolley Left | X23: 7 | K22 | Down contactor |
| K25-R1 | 1W Motor Supply | | Trolley Fast | X23: 8 | K25 | Hoist fast contactor |
| Ground | | | | | T100 | Transformer |
| PE | Motor | Terminal | | X24 Plug Pin No: | F100 | Fuse |
| PE | K10 | | | | | |
| PE | Trolley Connection | X1: 9 | Control voltage | X24: 1 | | |
| PE | Power Supply | X1: 10 | SD: low speed | X24: 2 | | |
| | | X1: 8 | F: Trolley Fast | X24: 3 | | |
| | | X1: 7 | D1: Trolley Rev | X24: 4 | | |
| | | X1: 6 | D2: Trolley Fwd | X24: 5 | | |


Control Panel Layout

Figure 16. Controls




5.15 2-Speed – 3-Phase – 208 / 230 / 460 Volt – Power Circuit

Figure 17. 2-Speed – 3-Phase – 2-8 / 230 / 460 Volt – Power Circuit




5.16 2-Speed – 3-Phase – 208 / 230 / 460 Volt – Control Circuit

Figure 18. 2-Speed – 3-Phase – 208 / 230 / 460 Volt – Control Circuit




5.18 2-Speed – 3-Phase – 575 Volt – Power Circuit

Figure 20. 2-Speed – 3-Phase – 575 – Power Circuit




5.19 2-Speed – 3-Phase – 575 Volt – Control Circuit

Figure 21. 2-Speed – 3-Phase – 575 Volt – Control Circuit



5.20 2-Speed – 3-Phase – 575 Volt – Push Button

Figure 22. 2-Speed – 3-Phase – 575 Volt – Push Button



6 PREVENTATIVE MAINTENANCE

6.1 Maintenance and Inspection Table

| CHECK | INTERVAL | QUALIFICATION OF PERSONNEL |
|--|----------------|----------------------------|
| VISUAL INSPECTION OF THE BRAKE OPERATION - FOR HOLDING AND RELEASING | DAILY | OPERATOR |
| VISUAL INSPECTION OF THE LOAD CHAIN | DAILY | OPERATOR |
| SUSPENSION OF THE PENDANT STATION | DAILY | OPERATOR |
| CLEANLINESS AND LUBRICATION OF THE CHAIN | MONTHLY | OPERATOR |
| CHECK THE OPERATION OF THE UPPER AND LOWER LIMIT SWITCHES | MONTHLY | OPERATOR |
| INSPECT THE CHAIN AND MEASURE FOR WEAR | EVERY 3 MONTHS | QUALIFIED INSPECTOR |
| INSPECT THE HOOKS AND MEASURE FOR WEAR | EVERY 3 MONTHS | QUALIFIED INSPECTOR |
| TIGHTNESS OF THE LOAD HOOK ASSEMBLY SCREWS & NUTS | EVERY 3 MONTHS | OPERATOR |
| CHECK THE LOCKING PLATE SCREWS FOR BODY HOOK OR COUPLING | EVERY 3 MONTHS | OPERATOR |
| ADJUSTMENT OF THE SLIP CLUTCH AND HOIST BRAKE | 3 TO 6 MONTHS | QUALIFIED MECHANIC |
| LUBRICATION OF OPEN WHEEL GEARING | 3 TO 6 MONTHS | QUALIFIED MECHANIC |
| TIGHTNESS OF WIRE TERMINAL SCREWS | SEMI-ANNUALLY | QUALIFIED MECHANIC |
| LUBRICATION OF THE 2-FALL LOAD BLOCK IDLER SPROCKET | ANNUALLY | OPERATOR |
| TIGHTNESS OF ALL SCREWS AND CHECK FOR SIGNS OF CORROSION | ANNUALLY | QUALIFIED MECHANIC |
| CLEAN MOTOR COOLING FINS | ANNUALLY | QUALIFIED MECHANIC |
| LUBRICATION OF THE GEARS | ANNUALLY | QUALIFIED MECHANIC |
| FUNCTION LABELS ON PENDANT STATION FOR LEGIBILITY | ANNUALLY | QUALIFIED INSPECTOR |
| INSPECT THE THRUST BEARING IN THE LOAD BLOCK | ANNUALLY | QUALIFIED MECHANIC |



CAUTION: These intervals shall be shortened if the hoist is used heavily with maximum loads or in extreme ambient conditions.

6.2 Lubrication

Figure 23. Lubrication




Table 6. Lubrication Specifications

| Lube Point | Specifications | Possible brands | Quantity |
|---|---|---|-----------------------|
| ■ Chain | Oil or liquid grease | Chain lubricating fluid (Ceplattyn or similar) EP-90 | As required |
| ▲ Idler sprocket Slide bearing + bearing | Grease (without MoS ₂) KP 2 (DIN 51 502) Soap-based lithium Approx. drip point +500 °F Worked penetration 509-563 °F Operating temperature -4 °F - +266 °F | BP: BP Energrease LS - EP 2 Esso: Unirex N2 Mobil: Mobilgrease HP Shell: Shell Alvanio EP Grease 2 | As required |
| ● Gears | Oil EP220 | Mobil: L-CKC220 BP: Energol XP220 Shell: Omala 150/220 | 1.6 liters 1 ¾ qts |

Open Wheel Gearing: EP1 Mobilux or equivalent.

6.3 Recommended Technical Support for Various Spare Parts

Table 7. Recommended Technical Support for Various Spare Parts

| SPARE PART | REPLACED BY |
|-----------------------------------|----------------------------------|
| Upper chain guide | Qualified electrician & mechanic |
| Output shaft | Qualified electrician & mechanic |
| PG cable gland | Qualified electrician |
| Gear input shaft + adjusting nuts | Qualified mechanic |
| Motor end cap | Qualified mechanic |
| Gearing (1st/2nd stage) | Qualified electrician & mechanic |
| Brake cap/end cap sealing | Qualified mechanic |
| Other seals and O-rings | Qualified mechanic |
| Brake-limiter | Qualified electrician |
| Brake end cap | Qualified mechanic |
| Lower chain guide | Qualified mechanic |
| Rubber buffer | Qualified mechanic |
| Electric box | Qualified electrician |
| PC-board | Qualified electrician |
| Plugs | Qualified electrician |
| Chain | Qualified mechanic |
| Chain container | Qualified mechanic |
| Slack fall stop | Qualified mechanic |
| Body hook | Qualified mechanic |
| Load hook assembly (1/1; 2/1) | Qualified mechanic |
| Control box | Qualified electrician |



NOTE: Once a part has been replaced, check the operation of the hoist per sections 3.3 and 3.4.

6.4 Screw Tightening Torque (lb-ft) Specification

Table 8. Torque Specifications (lb-ft)

| TYPE | M5 | M6 | M8 | M10 | M12 |
|---------------------|----|----|----|-----|-----|
| STANDARD SCREWS | 4 | 7 | 18 | 35 | 61 |
| SELF-TAPPING SCREWS | 4 | 6 | 15 | 30 | 53 |

6.5 Troubleshooting

Table 9. Troubleshooting

| Problem | Possible Cause | Possible Solution |
|---|---|--|
| Hoist does not lift or lower load | Emergency stop button is activated | Deactivate button |
| | Blown fuse | Replace the fuse |
| | Pendant plug pin pushed out | Reinstall plug pin |
| | Contactor terminal screws loose | Tighten screws |
| | Mainline switch shut off | Turn switch on |
| Hoist does not lift load | Overload condition | Reduce load |
| | Slip clutch worn or incorrectly adjusted | Replace wear items or re-adjust slip clutch torque |
| | Motor thermal protection activated | Allow motor too cool down |
| | Brake not releasing | Check brake coil resistance Check air gap setting. Adjust if necessary. Check rectifier output voltage |
| Load drifts more than 4 inches [100mm] | Brake lining worn Air gap on brake is too wide | Replace wear items on brake as necessary |
| Travel direction does not correspond to that indicated on push button | Power supply incorrectly connected | See section 3 |
| Abnormal noises while lifting or lowering | Load chain and its components are not lubricated | Clean/Lubricate load chain |
| | Load chain is worn | Replace chain |
| | Chain wheel or chain guide is worn | Replace chain wheel or chain guide |
| | Idler sprocket is worn | Replace idler sprocket |
| | A supply phase is missing | Connect the three phases |
| | Twist or kink in load chain | Remove twist or kink |

7 PARTS ILLUSTRATIONS

7.1 Basic Hoist Assembly

Figure 24. Basic Hoist Assembly




Table 10. Hoist Assembly Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|--|-----|
| 1 | - | SEE " CONTROLS" SECTION 7.6 | 1 |
| 2 | - | SEE " LIFTING ASSEMBLY" SECTION 7.4 & 7.5 | 1 |
| | | STANDARD BODY & CONTROL ASSEMBLIES | |
| | 2269955 | SM16 BODY (TS) 200-230V 1+3+4 | 1 |
| | 2269956 | SM16 BODY (TS) 460V 1+3+4 | 1 |
| | 2269957 | SM16 BODY (TS) 575V 1+3+4 | 1 |
| | 2279965 | SM20 BODY (TS) 200-230V 1+3+4 | 1 |
| | 2279966 | SM20 BODY (TS) 460V 1+3+4 | 1 |
| | 2279967 | SM20 BODY (TS) 575V 1+3+4 | 1 |
| | 2279968 | SM25 BODY (TS) 200-230V 1+3+4 | 1 |
| | 2279969 | SM25 BODY (TS) 460V 1+3+4 | 1 |
| | 2279970 | SM25 BODY (TS) 575V 1+3+4 | 1 |
| 3 | - | SEE "MOTOR & BRAKE ASSEMBLY" SECTION 7.3 | 1 |
| 4a | 2260500 | SM16/20 GEARBOX 113:1 32 / 8 FPM | 1 |
| 4b | 2270500 | SM25 GEARBOX 144.2:1 24 / 6 FPM | 1 |
| 5 | | SEE "LIFTING ASSEMBLY" SECTIONS 7.4 & 7.5 | 1 |
| 6a | 2279930 | CHAIN CONTAINER & PIN KIT 50FT-SM16 / 40FT-SM25 | 1 |
| 6b | 2279931 | CHAIN CONTAINER & PIN KIT 150FT-SM16 / 100FT-SM25 | 1 |
| 6c | 2279932 | CHAIN CONTAINER & PIN KIT SM20 & SM25 / 150FT MAX. | 1 |
| 7 | 2279912 | CHAIN CONTAINER PIN KIT | 1 |

7.2 Hoist Gearbox Components

Figure 25. Hoist Gearbox Components




Table 11. Gearbox Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|--|-----|
| 1 | 2260500 | SM16/20 GEARBOX ASSEMBLY – 113:1 – 32 / 8 FPM | 1 |
| 1 | 2270500 | SM25 GEARBOX ASSEMBLY – 144.2:1 – 24 / 6 FPM | 1 |
| 2 | 2279923 | SEAL SET | 1 |
| 3 | 2270000 | GEAR CASE HOUSING | 1 |
| 4 | 2279904 | GEAR SET – 2 nd REDUCTION | 1 |
| 5a | 2279902 | GEAR SET – 1 st REDUCTION – SM16/20 | 1 |
| 5b | 2279903 | GEAR SET – 1 st REDUCTION – SM25 | 1 |
| 6 | 2279905 | GEAR SET – 3 rd REDUCTION | 1 |
| 7 | 2406890001 | SM BRANDING BAND | 1 |
| 7a | | SM16 BRANDING STICKER SET | 1 |
| 7b | | SM20 BRANDING STICKER SET | 1 |
| 7c | | SM25 BRANDING STICKER SET | 1 |
| 8 | 2213309002 | HOIST BODY CAPACITY STICKER – ½ TON | 1 |
| 8 | 2213309003 | HOIST BODY CAPACITY STICKER – 1.0 TON | 1 |
| 8 | 2213309004 | HOIST BODY CAPACITY STICKER – 2.0 TON | 1 |
| 8 | 2213309008 | HOIST BODY CAPACITY STICKER – 500 KG | 1 |
| 8 | 2213309009 | HOIST BODY CAPACITY STICKER – 1000 KG | 1 |
| 8 | 2213309010 | HOIST BODY CAPACITY STICKER – 2000 KG | 1 |
| 8 | 2213309011 | HOIST BODY CAPACITY STICKER – 3200 KG | 1 |
| 8 | 2213309012 | HOIST BODY CAPACITY STICKER – 5000 KG | 1 |
| 8 | 2213309013 | HOIST BODY CAPACITY STICKER – 5.0 TON | 1 |
| 8 | 2213309014 | HOIST BODY CAPACITY STICKER – 1.5 TON | 1 |
| 8 | 2213309015 | HOIST BODY CAPACITY STICKER – 2.5 TON | 1 |
| 8 | 2213309016 | HOIST BODY CAPACITY STICKER – 1500 KG | 1 |
| 8 | 2213309017 | HOIST BODY CAPACITY STICKER – 2500 KG | 1 |
| 8 | 2213309019 | HOIST BODY CAPACITY STICKER – 4000 KG | 1 |
| - | 2213445001 | ELECTRICAL WIRING INFORMATION STICKER | 1 |
| - | 2213445002 | ELECTRICAL HAZARD WARNING STICKER | 1 |

7.3 SM16 / SM20 / SM25 Hoist Motor and Brake Assembly

Figure 26. Hoist Motor and Brake Assembly




Table 12. SM16/SM20/SM25 Hoist Motor and Brake Assembly Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|---|-----|
| 1a | 2245033 | SM16/SM20 MOTOR & BRAKE ASSY with PINION 208/230V | 1 |
| 1b | 2245031 | SM16/SM20 MOTOR & BRAKE ASSY with PINION 460V | 1 |
| 1c | 2245032 | SM16/SM20 MOTOR & BRAKE ASSY with PINION 575V | 1 |
| | | | |
| 1d | 2245038 | SM25 MOTOR & BRAKE ASSY with PINION 208/230V | 1 |
| 1e | 2245036 | SM25 MOTOR & BRAKE ASSY with PINION 460V | 1 |
| 1f | 2245037 | SM25 MOTOR & BRAKE ASSY with PINION 575V | 1 |
| | | | |
| 2 | 2279901 | BRAKE COVER END CAP & SCREW SET | 1 |
| 3 | 2275040 | FAN ASSEMBLY | 1 |
| | | | |
| 4a | 2275045 | MOTOR BRAKE ASSY 100VDC - 208/230VAC | 1 |
| 4b | 2275042 | MOTOR BRAKE ASSY 180VDC - 460VAC | 1 |
| 4c | 2275043 | MOTOR BRAKE ASSY 240VDC - 575VAC | 1 |
| | | | |
| 5a | 2275051 | ROTOR ASSEMBLY – TWO SPEED MOTOR | 1 |
| 5b | 2275052 | ROTOR ASSEMBLY – INVERTER MOTOR | 1 |
| | | | |
| 6 | 2275041 | BRAKE DISC ASSEMBLY | 1 |
| 7a | 2275049 | BEARING SET – TWO SPEED MOTOR | 1 |
| 7b | 2275050 | BEARING SET – INVERTER MOTOR | 1 |
| 8 | 2275046 | MOTOR END FLANGE – GEARBOX SIDE | 1 |
| 9 | 2275047 | MOTOR END FLANGE – BRAKE SIDE | 1 |
| 10 | 2275048 | SENSOR BEARING – INVERTER MOTOR | 1 |
| 11 | 2275053 | RETAINING RING AND SPLINED TUBE ASSEMBLY | 1 |

7.4 Lifting Assembly – SM16 Only

Figure 27. SM16 (Only) Lifting Assembly




Table 13. SM16 (Only) Lifting Assembly Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|--|-----|
| 1 | 2279955 | BODY HOOK SET (includes 2+3+4+5+6) | 1 |
| 1a | 2279914 | BODY HOOK SAFETY LATCH – STEEL PLATE TYPE | 1 |
| 2 | 2269915 | SM16 LOAD HOOK ASSEMBLY 2-FALL | 1 |
| 2a | 2279914 | SM16 HOOK SAFETY LATCH 2-FALL STEEL PLATE TYPE | 1 |
| 2b | 2267000 | SM16 LOAD HOOK 2-FALL | 1 |
| 2c | 2269916 | SM16 LOAD HOOK HOUSING SET | 1 |
| 2d | 2213405003 | CAPACITY STICKER – 2 TON – 2-FALL | 2 |
| 2d | 2213405004 | CAPACITY STICKER – 3 TON – 2-FALL | 2 |
| 2d | 2213405010 | CAPACITY STICKER – 2000 KG – 2-FALL | 2 |
| 2d | 2213405011 | CAPACITY STICKER – 3000 KG – 2-FALL | 2 |
| 3 | 2269900 | SM16 LOAD HOOK ASSEMBLY – 1-FALL | 1 |
| 3a | 001513 | SM16 HOOK SAFETY LATCH 1-FALL – WIRE TYPE | 1 |
| 3b | 2242021 | SM16 LOAD HOOK – 1-FALL | 1 |
| 3d | 2213405001 | CAPACITY STICKER – 1 TON – 1-FALL | 2 |
| 3d | 2213405002 | CAPACITY STICKER – 1.5 TON – 1-FALL | 2 |
| 3d | 2213405008 | CAPACITY STICKER – 1000 KG – 1-FALL | 2 |
| 3d | 2213405009 | CAPACITY STICKER – 1500 KG – 1-FALL | 2 |
| 4 | 2269913 | SM16 CHAIN SPROCKET SET | 1 |
| 4b | 2265502 | SM16 CHAIN GUIDE | 1 |
| 5 | 2269942 | SM16 SLACK FALL STOP | 1 |
| 6a | 2263500 | SM16 LOAD CHAIN – ZINC PLATED (STANDARD) | N |
| 6b | 2263502 | SM16 LOAD CHAIN – STAINLESS STEEL – CHECK CAPACITY | N |
| 7 | 2279930 | CHAIN CONTAINER AND MTG PIN SET – 50ft SM16 / 40ft SM20/25 | 1 |
| 7 | 2279931 | CHAIN CONTAINER AND MTG PIN SET – 150ft SM16 / 100ft SM20/25 | 1 |
| 7 | 2279932 | CHAIN CONTAINER AND MTG PIN SET – 150ft SM20/25 | 1 |
| 8 | 9995008 | CHAIN LUBE | 1 |

7.5 Lifting Assembly – SM20/25 Only

Figure 28. SM20/25 (ONLY) Lifting Assembly




Table 14. SM20/SM25 (Only) Lifting Assembly Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|--|-----|
| 1 | 2279955 | BODY HOOK SET (INCLUDES 2+3+4+5+6) | 1 |
| 1a | 2279914 | BODY HOOK SAFETY LATCH – STEEL PLATE TYPE | 1 |
| 2 | 2279915 | SM20/25 LOAD HOOK ASSEMBLY 2-FALL | 1 |
| 2a | 2279914 | SM20/25 HOOK SAFETY LATCH 2-FALL STEEL PLATE TYPE | 1 |
| 2b | 2277001 | SM20/25 LOAD HOOK 2-FALL | 1 |
| 2d | 2213406002 | CAPACITY STICKER – 3.0 TON – 2-FALL | 2 |
| 2d | 2213406005 | CAPACITY STICKER – 4.0 TON – 2-FALL | 2 |
| 2d | 2213406003 | CAPACITY STICKER – 5.0 TON – 2-FALL | 2 |
| 2d | 2213406009 | CAPACITY STICKER – 3000 KG – 2-FALL | 2 |
| 2d | 2213406013 | CAPACITY STICKER – 4000 KG – 2-FALL | 2 |
| 2d | 2213406010 | CAPACITY STICKER – 5000 KG – 2-FALL | 2 |
| 3 | 2279900 | SM20/25 LOAD HOOK – 1-FALL | 1 |
| 3a | 2242017 | SM20/25 HOOK SAFETY LATCH 1-FALL – WIRE TYPE | 1 |
| 3b | 2277000 | SM20/25 LOAD HOOK – 1-FALL | 1 |
| 3d | 2213405002 | CAPACITY STICKER – 1.5 TON – 1-FALL | 2 |
| 3d | 2213405003 | CAPACITY STICKER – 2.0 TON – 1-FALL | 2 |
| 3d | 2213405004 | CAPACITY STICKER – 3.0 TON – 1-FALL | 2 |
| 3d | 2213405009 | CAPACITY STICKER – 1500 KG – 1-FALL | 2 |
| 3d | 2213405010 | CAPACITY STICKER – 2000 KG – 1-FALL | 2 |
| 3d | 2213405007 | CAPACITY STICKER – 3000 KG – 1-FALL | 2 |
| 4 | 2279911 | SM20/25 CHAIN SPROCKET SET | 1 |
| 4b | 2275502 | SM20/25 CHAIN GUIDE | 1 |
| 5 | 2279942 | SM20/25 SLACK FALL STOP | 1 |
| 6a | 2273500 | SM20/25 LOAD CHAIN – ZINC PLATED (STANDARD) | N |
| 6b | 2273502 | SM20/25 LOAD CHAIN – STAINLESS STEEL – CHECK CAPACITY | N |
| 7 | 2279930 | CHAIN CONTAINER & MTG PIN SET – 50ft SM16 / 40ft SM20/25 | 1 |
| 7 | 2279931 | CHAIN CONTAINER & MTG PIN SET – 150ft SM16 / 100ft SM20/25 | 1 |
| 7 | 2279932 | CHAIN CONTAINER & MTG PIN SET – 150ft SM20/25 | 1 |
| 8 | 9995008 | CHAIN LUBE | 1 |

7.6 SM16 / SM20 / SM25 Electrical Control Assembly

Figure 29. Electrical Control Assembly




Table 15. SM16/SM20/SM25 Electrical Control Assembly Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|---|-----|
| 1 | 2263015 | CONTROL BOX (BASE + COVER) | 1 |
| 2 | 2263006 | CONTROL PANEL ASSEMBLY: 208/230/460V – 115V – 60HZ | 1 |
| 2 | 2263007 | CONTROL PANEL ASSEMBLY: 575V – 115V – 60HZ | 1 |
| 2a | 2309564005 | CONTACTOR K10 – 208/230/460/575V – 115V CONT | 1 |
| 2b | 2309564006 | CONTACTOR K21 or K22 – 208/230/460/575V – 115V CONT | 1 |
| 2c | 2309568004 | CONTACTOR K25 – 208/230/460/575V – 115V CONT | 1 |
| 2d | 7983026 | TRANSFORMER – 208/230/460V - 115V | 1 |
| 2d | 7983027 | TRANSFORMER – 575V - 115V | 1 |
| 2e | 2243060 | BRAKE RECTIFIER 4 – WIRES 208 – 575VAC | 1 |
| 2e | 2243061 | BRAKE RECTIFIER 5 – WIRES 208 – 460VAC (RECONNECT) | 1 |
| 3 | 2249979 | 1.25 AMP FUSES – SET OF 10 | 1 |
| 4 | 2249947 | POWER CABLE GLAND | 1 |
| 5 | 2219814 | COVER PLATE – USED WHEN PLUG IS REMOVED | 1 |
| 6 | 2249946 | PLUG FOR TROLLEY CIRCUIT | 1 |
| 6 | 2249982 | POWER PLUG – OPTIONAL | 1 |
| 6 | 2249945 | PLUG FOR PENDANT | 1 |
| 7a | 2269010 | SM16 SPRING & WASHER ASSEMBLY – 1-FALL | 2 |
| 7a | 2269010 | SM16 SPRING & WASHER ASSEMBLY – 2-FALL | 3 |
| 7b | 2279010 | SM20/25 SPRING & WASHER ASSEMBLY – 1-FALL | 2 |
| 7b | 2279010 | SM20/25 SPRING & WASHER ASSEMBLY – 2-FALL | 3 |
| 8 | 7291050 | SM16/20/25 U/L LIMIT MICRO SWITCH | 2 |
| 9 | 2269004 | SM16/20/25 U/L LIMIT SWITCH LEVER ASSEMBLY | 1 |
| - | 2263050 | SM16/20/25 U/L LIMIT SWITCH ASSEMBLY | 1 |
| - | 2213445001 | ELECTRICAL WIRING INFORMATION STICKER | 1 |
| - | 2213445002 | ELECTRICAL HAZARD WARNING STICKER | 1 |

7.7 Push Button Assembly –Vertical Pairs of Buttons

Figure 30. Push Button Assembly – Vertical Pairs of Buttons




Table 16. Push Button Assembly Parts List

| ITEM | PART NUMBER | DESCRIPTION | QTY |
|------|-------------|--|-----|
| 1a | 2309673010 | P/B ASSEMBLY – 10 FT, E-STOP, SS HOIST | 1 |
| 1b | 2309673015 | P/B ASSEMBLY – 15 FT, E-STOP, SS HOIST | 1 |
| 1c | 2309673020 | P/B ASSEMBLY – 20 FT, E-STOP, SS HOIST | 1 |
| 2 | 2218000 | UPPER SUSPENSION KIT | 1 |
| 3 | 2219812 | PLUG KIT – P/B ASSEMBLY | 1 |
| 4 | 2212752001 | STRAIN RELIEF CABLE | 1 |
| 5 | 2212753001 | SUSPENSION UNIT | 1 |
| 6 | 52292266 | P/B ELECTRICAL CABLE – 16 GAUGE / 12 CONDUCTOR RPC | 1 |
| 7a | 2212932011 | P/B ENCLOSURE ASSEMBLY: E-STOP, SH | 1 |
| 7b | 2212932012 | P/B ENCLOSURE ASSEMBLY: E-STOP, TH | 1 |
| 7c | 2212932032 | P/B ENCLOSURE ASSEMBLY: E-STOP, SH, TT | 1 |
| 7c | 2212932033 | P/B ENCLOSURE ASSEMBLY: E-STOP, TH, TT | 1 |
| 8 | 2309414001 | R&M OPERATOR'S WARNING TAG - ENGLISH | 1 |